


How to use The Rushton.

Push on the paddle to open up your gripper. You can then slide in anything that you want to hold and let go of the paddle to close the gripper.



You can use me for:

- Holding small round or flat items such as:
- Mug handles
- Phones
- Holding paper down
- Holding books/magazines

Please don't use me for:

- ✗ Lifting objects over the mass of 0.5 kg,
- ✗ Lifting mugs with hot drinks if it feels unstable

Please refer to your Paww user guide for guidance on attaching and taking off your tool.